

GROUND MOUNT EXTENSION 14-INCH RAILS WITH SPLICES

Extend Ground Mount
Rails by 14-inches to
mount modules up to
46 inches in width on
Tamarack Ground Mounts

- Kit contains two 14-inch sections of 3.1 rail and two splices with hardware
- Rails with structural splices can be installed at one end of a rail or between longer sections



Installation Instructions

The 3.1 Rail Splice comes with two channel nuts that allow the splice to be clamped in place. Insert the Rail Splice 5-inches into one rail end. Install one bolt and channel nut (roughly centered in the 5-inch insertion) and tighten to hold it in place. Slide the second section of rail over the splice until it contacts the first section of rail and install the second bolt and chanel nut. Tighten both bolts to 144 inch-pounds (12 foot-pounds). Either locking bolt may be loosened and moved slightly if it interferes with mid-clamp placement when installing modules.



